


nÂ°	Artikel	Aantal gebruikt
	STANDARD ACCESSORIES	0
	OPTIONAL ACCESSORIES	0
1	321132 BLADE HOLDER (A)	1
2	322709 NUT M4 (BLACK)	1
3	324472 PLUNGER	1
4	996401 PACKING WASHER	1
5	996400 FELT PACKING	1
6	996407 O-RING (1AP-12)	1
7	956589 METAL	2
8	324471 UPPER COVER	1
9	305583 HEX. HOLE BOLT M5X20 (NEW 6695491)	2
10	322134 SPECIAL BOLT M4	1
11	321130 CAP	1
12	321131 LEVER (A)	1
13	321135 SPRING (D)	1
14	321134 HOLDER PIN (B)	1
15	318483 SPRING (B)	1
16	319866 BASE	1
17	951039 MACHINE SCREW (W/SP.WASHER) M4X12	5
18	324474 COVER PLATE	1
19	324473 FRONT COVER	1
20	993244 SEAL LOCK FLAT HD. SCREW M4X12	3
21	319849 BEARING COVER (B)	1
22	6901VV BALL BEARING 6901VVCMP2L	1
23	319848 SPINDLE	1
24	954789 METAL (B)	1
25	996399 HEX.SOCKET HD.BOLT M5X12 (W/FLANGE)	1
26	986011 TAPPING SCREW D5X30 (W/SP.WASHER)	4
27	319844 GEAR COVER ASS'Y	1
28	319875 SEALLOCK HEX.SOCKET HD BOLT M5X12	2
29	319851 NYLOCK HEX. SOCKET HD BOLT M6X16	1
30	319856 SEAL PACKING	1
31	319874 PACKING (B)	1
32	983567 CONNECTOR HOLDER	1
33	996405 CONNECTOR (OLD 983568)	1
34	983541 CONNECTING PIECE (A) (OLD 983566)	1
35	324470 NEEDLE ROLLER H-7108 (OLD 983560)	1
36	319852 BALANCE WEIGHT	1

nÂ°	Artikel	Aantal gebruikt
37	324469 GEAR	1
38	670514 RETAINING RING (E-TYPE)	1
39	6001VV BALL BEARING 6001VV	1
40	319843 BEARING COVER (A)	1
41	360703 ARMATURE ASS'Y DC 18V	1
42	608VVM BALL BEARING 608VVC2PS2L	1
43	324468 MAGNET	1
44	324478 BRUSH BLOCK	1
44A	334888 BRUSH BLOCK SET	1
45	324475 HOUSING SET (A+B)	1
46	319847 BRUSH CAP	2
47	999068 CARBON BRUSH (1 PAIR) (OLD 999058)	2
48	HITACHI LABEL	1
49	CAUTION LABEL	1
50	324517 TERMINAL PIECE SET	1
51	319760 PUSHING BUTTON	1
52	319861 DC-SPEED CONTROL SWITCH	1
53	NAME PLATE	1
54	302086 TAPPING SCREW D4X20 (W/FLANGE) BLACK	8
55	CAUTION PLATE	1
56	319812 HEAT SINK	1
57	993963 MACHINE SCREW M3X12 (W/WASHERS)	1
58	305574 HEX.SOCKET HD.BOLT M5X16	2
59	326353 CAP (A)	1
501	318613 SABER SAW BLADES NO.103 150L P.14 (5 PCS)	1
502	944458 HEX. BAR WRENCH 4MM	1
503	324313 CASE	1
504	CHARGER (MODEL UC18YRL)	1
601	326241 BATTERY EBM 1830 (USA,CAN)	1
604	958182 SABER SAW BLADES NO.2 (5 PCS.)	1
605	958183 SABER SAW BLADES N.3 (NEW 750057)	1
606	959611 SABER SAW BLADES NO.4 (5 PCS.)	1
607	958185 SABER SAW BLADES NO.5 (5 PCS.)	1
608	958188 SABER SAW BLADES NO.8 (5 PCS.)	1
609	996427 SABER SAW BLADES NO.9 (3 PCS.)	1
610	959799 SABER SAW BLADES NO.95 (3 PCS.)	1
611	959800 SABER SAW BLADES NO.96 (3 PCS.)	1
612	318611 SABER SAW BLADES NO.101 150L P.10 (5 PCS)	1

nÂ°	Artikel	Aantal gebruikt
613	318612 SABER SAW BLADES NO.102 228L P.10 (5 PCS	1
615	318614 SABER SAW BLADES NO.104 228L P.14 (5 PCS	1
616	318617 SABER SAW BLADES NO.107 150L P.24 (5 PCS	1
617	318618 SABER SAW BLADES NO.108 228L P.24 (5 PCS	1
618	324818 SABER SAW BLADES NO.109 150L P.18 (5 PCS	1
619	324819 SABER SAW BLADES NO.110 228L P.18 (5 PCS	1
620	318619 SABER SAW BLADES NO.121 305L P.6 (5 PCS.	1
621	318620 SABER SAW BLADES NO.131 305L P.10/14(5PC	1
622	318621 SABER SAW BLADES NO.132 203L (5 PCS.)	1



Rev.3

形 名
CR18DL