


nÂ°	Artikel	Aantal gebruikt
	STANDARD ACCESSORIES	0
1	311959 SPECIAL SCREW M6X23 (LEFT HAND)	1
2	323898 DRILL CHUCK 13VLRN-N (W/O CHUCK WRENCH)	1
3	324061 GEAR BOX ASS'Y	1
4	324074 FRONT CAP	1
5	324136 SWITCH PLATE	1
6	324064 NUT	1
7	324135 SPRING	1
8	324063 THRUST WASHER	1
9	322972 STOPPER	2
10	322971 STOPPER SPRING	2
11	324062 FRONT CASE	1
12A	323231 CLICK SPRING	1
13	322975 PIN SET (6 PCS)	6
14	324065 WASHER (D)	1
15	322976 LOCK RING	1
16	324066 RING GEAR	1
17	322978 CARRIER	1
18	324067 PLANET GEAR (C) SET (5 PCS)	5
19	322980 WASHER (A)	1
20	322981 REAR CASE	1
21	322990 SHIFT ARM	1
22	320087 SCREW SET M3X12 (4 PCS.)	4
23	324069 SLIDE RING GEAR	1
24	324068 PINION (C)	1
25	324070 PLANET GEAR (B) SET (4 PCS)	4
26	324071 PINION (B)	1
27	324073 PLANET GEAR (A) SET (4 PCS)	4
28	324072 FIRST RING GEAR	1
29	322988 WASHER (B)	1
30	322989 MOTOR SPACER	1
31A	360996 ARMATURE & PINION SET 18 VOLT (OLD 360701)	1
32	322996 MAGNET	1
33	322993 BRUSH BLOCK (NEW 338733)	1
34	999054 CARBON BRUSH 5X6X11.5 (1 PAIR)	2
35	319918 BRUSH CAP	2
36	313687 TAPPING SCREW (W/FLANGE) D3X16 (BLACK)	1
37	NAME PLATE	1

nÂ°	Artikel	Aantal gebruikt
38	326278 HOUSING SET (A+B)	1
39	326279 PLATE (A)	1
40	326276 LEVER (A)	1
41	324137 SHIFT KNOB	1
42	326277 LEVER (B)	1
43	326493 SUPPORT (D)	1
44	323229 FERRITE CORE	1
45	322997 PUSHING BUTTON	1
46	333640 DC-SPEED CONTROL SWITCH (OLD 322994)	1
47	HITACHI LABEL	1
48	958715 TAPPING SCREW D4X10	2
49	996118 HOLDER SPRING	2
50	323003 TERMINAL	1
51	320997 TERMINAL PIECE	1
52	322995 TERMINAL	1
53	320287 HOOK ASS'Y	1
54	320288 V-LOCK NUT M5	1
55	321918 HOOK ASS'Y (W/LIGHT)	1
56	321672 TAPPING SCREW D2X6	2
57	306952 STRAP (BLACK)	1
58	319926 HOOK SPRING	1
59	320881 SPECIAL SCREW M5 (A)	1
60	326241 BATTERY EBM 1830 (USA,CAN)	2
60	326240 BATTERY EBM 1830 (EUROPE,AUS,NZL)	2
61	CAUTION PLATE	1
501	CHARGER (MODEL UC 18YGL2)	1
501	CHARGER (MODEL UC 18YRL)	1
502	983006 + DRIVER BIT NO.2 65L	1
503	323001 SIDE HANDLE	1
504	323230 CASE	1



形 名
DV18DL

Rev.3