

| nÂ° | Artikel                            | Aantal gebruikt |
|-----|------------------------------------|-----------------|
| 1   | 331978 COLLET NUT                  | 1               |
| 2   | 331969 COLLET D3.2                 | 1               |
| 3   | CAP                                | 1               |
| 4   | 331970 FELT                        | 1               |
| 5   | 332519 HOUSING SET (A+B)           | 1               |
| 6   | 331971 LOCK PIN                    | 1               |
| 7   | 319267 SPRING                      | 1               |
| 8   | 331973 MOTOR DC 10.8 VOLT          | 1               |
| 10  | 331972 HOOK                        | 1               |
| 12  | HITACHI LABEL                      | 1               |
| 13A | 334850 CONTROLLER SET (OLD 331977) | 1               |
| 13  | 331977 CONTROLLER                  | 1               |
| 501 | CHARGER (MODEL UC 10SFL)           | 1               |
| 502 | 332491 CASE                        | 1               |
| 503 | 332492 ACCESSORIES SET (A)         | 1               |
| 504 | 332493 ACCESSORIES SET (B)         | 1               |

